



Figurando aqui comenda e empreenda o reparo ou a substituição das peças com vícios de qualidade de fabricação, após análise de técnicos especializados da Via Varejo.

NESTE FURO

F 24x	P 48x	T 03x
B 12x	Q 72x	ATEN NAS C
M 12x	AH² 12x	

A horizontal beam is shown with two downward-pointing arrows representing loads. The beam is divided into three equal segments by vertical dashed lines. Each segment contains the text "0.0 =".

Diagram 10 shows the shelf being attached to the side panel. A circular inset provides a close-up view of the shelf being placed onto the side panel, with a black arrow indicating the direction of movement. The shelf is labeled with a black box containing the number 10. The side panel is labeled with a black box containing the number 10. The shelf is being attached to the side panel using a metal bracket and a screw.

Passo 14

EFEITUAR O ENCAIXE DAS CORREDIÇÃOS NOS DOIS LADOS SIMULTANEAMENTE.

COLOCAR AFERRAGEM X JUNTO COM O CABINEIRO.

**FIXAR OS PUXADORES NOS
3 FUROS DE BAIXO
CONFORME ILUSTRADO
ABAIXO.**

REGULAR AS PORTAS E COLUNAS A FERRAGEM A

Após Regular travamento em toda

Diagram illustrating the assembly of a cable bracket:

- Components:**
 - A: Bracket
 - Z: Cable
 - D: Screw
 - P: Washer
 - N: Nut
- Assembly Steps:**
 - Attach the bracket (A) to the wall using a screw (D).
 - Insert the cable (Z) into the bracket.
 - Secure the cable with a nut (N) and washer (P).